



Manual

TouchMonitor TMR7

Software Version 8-02 | 11.2019



RTW
EYES ON YOUR AUDIO

Gefördert durch:



aufgrund eines Beschlusses
des Deutschen Bundestages





Schnellstart-Anleitung TouchMonitor TMR7 Serie

DE

Ab Software-Version 8-02 | 11.2019



Schnellstart-Anleitung

für

RTW TouchMonitor TMR7 Serie

Manual-Version: 3.0

Erstellt: 20.11.2019

Software-Version: 8-02 und höher (11.2019)

© **RTW** 11/2019 | Technische Änderungen vorbehalten!

RTW GmbH & Co. KG

Am Wassermann 25 | 50829 Köln | Germany

Fon +49 221. 70 913-0 | Fax +49 221. 70 913-32

rtw@rtw.com | www.rtw.com

WEEE-Reg.-Nr.: DE 90666819

RoHS-Konformität: Diese Geräte erfüllen als Überwachungs- und Kontrollinstrumente in der Kategorie 9, Anhang 1, die Vorschriften der Richtlinie des Europäischen Parlamentes und des Rates vom 8. Juni 2011 zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten.



Bitte **lesen** Sie die folgenden Anweisungen sorgfältig, **verstehen** Sie sie und **handeln** Sie nach diesen Vorschriften, um jegliche Gefahren zu vermeiden oder Gesetze nicht zu verletzen.

Hinweise:

Die Abbildungen in dieser Bedienungsanleitung sind sorgfältig erstellt und dienen der Illustration des Beschriebenen. Trotzdem können sie von der Darstellung auf Ihrem Gerät geringfügig abweichen.

Die aktuelle Version der Bedienungsanleitung und verfügbare Firmware/Firmware-Updates finden Sie unter „Audio-Monitore“/„Touch-Monitor TMR7“ im Mitglieder-Bereich auf unserer Web-Seite:
<https://www.rtw.com/de/support/manuals-software.html> (Anmelde-Seite).

Im Lieferumfang ist ein USB-Speichermedium einer Zulieferfirma enthalten. Die Firma Shenzhen BSE Technology Co., Ltd. erklärt die CE-Konformität (E07002566) und die RoHS-Konformität (R0808179) des Mediums.

Eine detaillierte RoHS-Konformitätserklärung zur TouchMonitor TMR7 Serie finden Sie im Anhang.

Sicherheitshinweise

DE

Die folgenden Symbole sind auf dem Gehäuse des Gerätes, auf einzelnen Modulen und in dieser Bedienungsanleitung zu finden:



WARNUNG!

Dieses Symbol warnt Sie vor einer möglicherweise gefährlichen Situation, etwa vor gefährlichen Spannungen, die Sie einem elektrischen Schock aussetzen könnten. Achten Sie auf den Warnhinweis und handeln Sie besonders vorsichtig.



ACHTUNG!

Dieses Symbol macht Sie auf wichtige Bedienhinweise oder auf mögliche Bedienfehler aufmerksam, die zur Beschädigung von Geräten führen könnten. Wenn Sie dieses Zeichen auf einem Gerät finden, beachten Sie die Hinweise in der Bedienungsanleitung zu entsprechenden Vorsichtsmaßnahmen.



HINWEIS

Dieses Symbol weist Sie auf Besonderheiten hin, bei denen es sich nicht um Fehlfunktionen handelt.

Allgemeine Sicherheitsanweisungen

- Lesen Sie die Anleitung. Vor Inbetriebnahme des Gerätes studieren Sie sorgfältig und verstehen Sie alle Sicherheits- und Bedienungsanweisungen!
- Bewahren Sie die Sicherheits- und Bedienungsanweisungen zum späteren Nachschlagen auf!
- Beachten Sie alle Warnhinweise auf dem Gerät und befolgen Sie die Sicherheits- und Bedienungsanweisungen, bevor Sie das Gerät installieren und betreiben!
- Befolgen Sie immer diese Anweisungen, um Schaden für sich, am Gerät oder an angeschlossenen Geräten zu vermeiden!



Um einen möglichen Stromschlag, Brand, Schaden oder Fehlfunktionen zu verhindern, benutzen Sie bitte das Gerät nur wie vorgesehen. Die Geräte sind für den Einsatz in geschlossenen Räumen vorgesehen und dürfen nur mit dem dafür zugelassenen Netzteil betrieben werden.

WARNUNG!

Folgen Sie immer den Sicherheitsmaßnahmen, um schwerwiegende Verletzungen oder gar Tod durch elektrischen Schlag, Kurzschluss, Schäden, Feuer oder andere Risiken zu vermeiden. Diese Maßnahmen beinhalten die folgenden Punkte, sind aber nicht auf diese beschränkt:

- Öffnen Sie nicht das Gehäuse. Innerhalb des Gerätes befinden sich keine Teile, die der Wartung durch den Benutzer bedürfen. Überlassen Sie Wartungsarbeiten stets nur dem Hersteller.
- Versuchen Sie nicht, irgendetwas zu reparieren. Reparaturen dürfen nur von qualifiziertem Personal durchgeführt werden.
- Entfernen Sie keine Teile aus dem Gerät und führen Sie keine Modifikation am Gerät aus ohne die schriftliche Freigabe durch RTW. Veränderungen am Gerät können sowohl Sicherheitsrisiken verursachen als auch die Konformität und Zertifizierungen beeinflussen.
- Verwenden Sie nur geeignete Netzkabel bzw. Netzgeräte. Verwenden Sie ausschließlich Netzkabel und Netzteile, die für dieses Gerät freigegeben und in Ihrem Land zertifiziert sind.
- Beachten Sie alle Anschlusswerte und Markierungen auf dem Gerät. Informieren Sie sich in der Bedienungsanleitung über weitere Details zu den Anschlusswerten, bevor Sie etwas anschließen.
- Verbinden Sie keinen der Anschlüsse mit Stromquellen, deren Anschlusswerte die des Geräteanschlusses übersteigen.
- Vermeiden Sie den Kontakt mit offenliegenden Schaltungsteilen- und Bauelementen bei anliegender Stromversorgung.
- Durch Abziehen des Netzkabels des externen Netzteils kann das Gerät vom Stromnetz getrennt werden. Blockieren Sie das Netz-
kabel und das Netzteil nicht, es muss für den Anwender jederzeit erreichbar bleiben.
- Schalten Sie das Gerät sofort aus und trennen Sie es sofort vom Stromnetz, wenn ungewöhnliche Gerüche, Geräusche oder Rauch auftreten oder wenn Fremdstoffe (z. B. Flüssigkeiten) oder fremde Gegenstände eindringen.
- Halten Sie das Gerät wegen der eingebauten Batterie unbedingt von exzessiver Hitze wie Sonneneinstrahlung, Feuer oder ähnlichem fern.
- Vorsicht: Es besteht die Gefahr der Explosion wenn eine falsche Batterie eingesetzt wird. Verwenden Sie immer den definierten oder äquivalenten Typ.
- Decken Sie das Gerät nicht ab und stellen Sie keine Gegenstände oder Behälter mit Flüssigkeiten darauf ab.
- Stecken Sie keine Finger oder andere Gegenstände ins Gehäuse.
- Betreiben Sie das Gerät niemals mit entfernten Gehäuseteilen.
- Kein Betrieb bei Verdacht auf Fehler. Wenn Sie dies vermuten, lassen Sie es durch qualifizierte Servicetechniker prüfen.
- Betreiben Sie das Gerät nicht in der Nähe von Wasser.
- Betreiben Sie das Gerät nicht in nassen bzw. feuchten Umgebungen.
- Betreiben Sie das Gerät nicht in explosionsgefährdeten Umgebungen.
- Betreiben Sie das Gerät nicht in staubigen Umgebungen.

ACHTUNG!

Folgen Sie immer den Sicherheitsmaßnahmen, um Verletzungen oder Beschädigungen am Gerät oder anderen Objekten zu vermeiden. Diese Maßnahmen beinhalten die folgenden Punkte, sind aber nicht auf diese beschränkt:

- Blockieren Sie keine Lüftungsöffnungen. Installieren Sie das Gerät entsprechend der Anweisungen zur Sicherstellung einer adäquaten Belüftung, um einen zu hohen Temperaturanstieg im Inneren zu vermeiden.
- Setzen Sie es deshalb auch keiner direkten Sonneneinstrahlung aus.
- Halten Sie die Oberflächen des Gerätes sauber und trocken. Benutzen Sie ein weiches trockenes Tuch.
- Verwenden Sie zur Reinigung der Gehäuseoberflächen und des Displays niemals lösemittelhaltige Flüssigkeiten (wie z. B. Benzin, Spiritus, Alkohol, u. a.).
- Stellen Sie das Gerät nicht in einer instabilen Position auf. Es könnte unbeabsichtigt hinfallen oder herunter stürzen.
- Stellen Sie sicher, dass das Gerät nicht an das Netzteil angeschlossen ist. Schließen Sie erst dann andere Geräte an.
- Schützen Sie das Netzkabel vor Hängenbleiben oder Einklemmen, besonders im Bereich von Anschlüssen, Steckdosen und Stellen, an denen das Netzkabel aus dem Gerät kommt.
- Trennen Sie das Gerät vom Netz während eines Gewitters oder wenn es länger nicht verwendet wird.
- Entfernen Sie erst alle Kabel, bevor Sie das Gerät an einen anderen Platz stellen.
- Achten Sie beim Transport darauf, die Gehäuseoberfläche und das Display nicht zu verkratzen oder anderweitig zu beschädigen.
- Überlassen Sie Reparaturen stets dem qualifizierten Service-Personal. Reparaturen sind erforderlich bei jeglicher Art von Beschädigung insbesondere bei beschädigtem Netzkabel oder Netzstecker, Beschädigung durch übergelaufene Flüssigkeiten, beim Eindringen von Gegenständen, wenn das Gerät Regen oder Feuchtigkeit ausgesetzt war, wenn es nicht ordnungsgemäß arbeitet oder wenn es gefallen ist.

Information zur eingebauten Pufferbatterie

Auf der Platine befindet sich eine Batteriehalterung, in die eine 3 V Li/Mn-Knopfzelle Typ CR 1225 mit dem Plus-Pol nach oben und dem Minus-Pol nach unten (in Richtung Platine) seitlich eingeschoben ist.

DE

Umweltschutz

Beachten Sie die folgenden Informationen zur Umweltverträglichkeit des Gerätes und die Hinweise, wenn Sie ein Gerät oder Bauteile recyceln möchten (Handhabung am Ende der Produktlebensdauer):

- **Wiederverwertung des Gerätes**

Bei der Herstellung dieses Gerätes wurden natürliche Ressourcen eingesetzt und verbraucht. Das Gerät kann Substanzen beinhalten, die bei unsachgemäßer Entsorgung schädlich für die Umwelt oder für den Menschen sein könnten. Um die Freisetzung solcher Substanzen in die Umwelt zu verhindern und den Verbrauch natürlicher Ressourcen zu reduzieren, bitten wir Sie, das Gerät so zu recyceln, dass der größte Teil der Inhaltsstoffe auf geeignete Weise erneut verwendet oder verwertet werden kann.

- **Batterie-Recycling**

Dieses Gerät enthält eine Lithium-Mangan- (Li/Mn-) Batterie, die auf geeignete Weise wiederverwertet oder entsorgt werden muss. Bitte verwerten oder entsorgen Sie diese Batterie entsprechend den gesetzlichen Bestimmungen in Ihrem Land.

- **Vermeidung giftiger Substanzen**

Diese Geräte erfüllen als Überwachungs- und Kontrollinstrumente in der Kategorie 9, Anhang 1, die Vorschriften der Richtlinie des Europäischen Parlamentes und des Rates vom 8. Juni 2011 zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten. Die Geräte können in geringen Mengen Blei, Cadmium und/oder Quecksilber enthalten. Bitte verwerten oder entsorgen Sie die elektronischen Teile und Baugruppen entsprechend den gesetzlichen Bestimmungen in Ihrem Land.

Inhaltsverzeichnis

Sicherheitshinweise 3

Allgemeine Sicherheitsanweisungen 3

Warnung! 4

Achtung! 5

Umweltschutz 6

Inhaltsverzeichnis 7

Bevor Sie beginnen 8

Einleitung 8

Lieferumfang 10

Installation 11

Anschlüsse 12

Pin-Belegung 13

Schnellstart 15

Inbetriebnahme 15

Anpassung des TouchMonitors an Ihr Audio-System 16

Erstellen eigener Presets 18

Arbeiten mit Instrumenten und Presets 23

Mitgelieferte Presets 25

Software-Module (Lizenz-Abwicklung) 42

Software-Update 46

Technische Daten (Auszug) 48

CE-Konformitätserklärung 50

RoHS-Konformitätserklärung 51

CE und RoHS von Zulieferfirmen 52

Lizenzen der implementierten Software 53

DE

Bevor Sie beginnen



Einleitung

Vielen Dank für den Erwerb eines Modells aus der TouchMonitor TMR7 Serie. Loudness, True Peak, PPM, Audio-Vektorskop, Moving Coil-Instrumente, RTA und Korrelation - der vierkanalige TouchMonitor TMR7 mit 7"-Touch Screen und dem einzigartigen Bedienkonzept der TouchMonitor-Baureihe bündelt die im Hörfunk relevante Audio-Messtechnik in einer maßgeschneiderten Lösung.



Einfach und flexibel

Die grafische Bedienoberfläche des TouchMonitors steuern Sie ganz einfach mit Ihrem Finger. Instrumente können so skaliert, beliebig positioniert und auf vielfältige Weise kombiniert werden, um die Bildschirmfläche so effizient wie möglich zu nutzen. Dabei können auch mehrere Instrumente des gleichen Typs, die unterschiedliche Signalquellen anzeigen, parallel dargestellt und unabhängig konfiguriert werden. Eine komfortable Bildschirm-Hilfe macht Änderungen an der Konfiguration zum Kinderspiel.

Audio-Schnittstellen (I/O-Optionen)

Dabei ist der TouchMonitor TMR7 hard- und softwareseitig zielgenau auf die Anforderungen des Hörfunks abgestimmt und lässt sich perfekt in heutige Studio-Umgebungen integrieren. Die vier Audio-Eingangskanäle der beiden AES3-I/Os im XLR-Format lassen sich in beliebigen Kombinationen als Mono-, Stereo- oder Mehrkanal-Quellen mit jeweils unabhängigen Instrumenten konfigurieren. So ist z. B. die parallele Überwachung des Sendesignals und einer vorgehörten Quelle möglich.

Lizenzen


Ein vollständig modulares Softwarekonzept sorgt dafür, dass Sie nur noch solche Funktionen erwerben, die Sie auch tatsächlich benötigen. Sie haben die Wahl - und definieren selbst den Funktionsumfang Ihres TouchMonitors, der Ihr individuelles Anforderungsprofil perfekt erfüllt. Neue Instrumente und Funktionen können dem Gerät in Form von Software-Modulen jederzeit hinzugefügt werden. Viele bekannte Anzeigefunktionen stehen dabei zur Wahl: der Real-Time-Analyzer (RTA), die Loudness-Messung gemäß allen relevanten Loudness-Standards mit LRA und Chart und das Premium PPM mit Audio-Vektorskop und Zeigerinstrumenten (Moving Coil).



Lieferumfang


Packen Sie das Instrument aus, finden Sie unten Ihre Version und prüfen Sie, ob Sie alle entsprechenden Komponenten erhalten haben. Falls Teile fehlen, wenden Sie sich bitte an Ihren Händler. Passende Optionen und Software-Lizenzen sind ebenfalls aufgelistet.

TouchMonitor TMR7



Tischgerät TMR7

➤ mit Audio-Schnittstelle



2 x AES3 In
2 x AES3 Out


➤ Software-Lizenz, falls bestellt




Loudness and
SPL display
SW20002




RTA - Real Time
Analyzer
SW20003




Premium PPM
+ Moving Coil
SW20006



Timecode
Reader
SW20008



Logging Data
Server (+Chart)
SW20014




USB-Stick



Schnellstart-Anleitung


➤ Netzteil



USB-Stick



Schnellstart-Anleitung



OEM-Version TMR7OEM

Installation

Das TouchMonitor **TMR7** Tischgerät wurde für die freie Platzierung auf Tischen, Pulten, u. a. entwickelt. Die OEM-Version **TMR7OEM** ist für den Einbau in Frontplatten, z. B. Mischpultkonsolen, konzipiert. Diese kann mit dem optionalen Montagesatz **TM7-MA3U** in übliche 19"/3HE-Racks und mit dem optionalen Montagesatz **TM7-MAVID** in Standard-19"-Einbaugehäuse für Video-Racks eingebaut werden. Zudem kann sie mit **TM7-MADT** in ein Tischgerät umgebaut werden. Alle zum Betrieb notwendigen Versorgungsspannungen werden über den 4-poligen DC-Einbaustiftstecker (+24 V - 1 A) mittels des externen RTW Weitspannungsnetzteils **1178-R** eingespeist (bei TMR7 im Lieferumfang, optional für TMR7OEM). Die Geräte verfügen über einen 7"-TFT-Touch-Screen (VGA, 16 : 9).

Optional kann zum Ablesen aus größerer Entfernung ein externer handelsüblicher VGA-Monitor (16 : 9) angeschlossen werden.

Optional kann zur Steuerung auch eine Maus oder ein Wacom®-Grafik-Tablett an einer der USB-Schnittstellen angeschlossen werden.

Alle Schnittstellen werden mit handelsüblichen Verbindungskabeln angeschlossen.



ACHTUNG – Bitte vor Inbetriebnahme lesen:

- Beachten Sie vor der Inbetriebnahme alle Sicherheitshinweise und die Informationen zu den Anschlüssen und der Pin-Belegung.
- Bei einer externen Stromversorgung mit 24 V DC ist eine externe Überstrombegrenzung auf 2 A zwingend vorzusehen!
- Stellen Sie sicher, dass das externe Netzteil nicht angeschlossen ist.
- Stellen Sie das Gerät an einem geeigneten Platz auf oder bauen Sie es entsprechend der Vorgaben (OEM) ein.
- Schließen Sie Ihre Signalquellen und alle weiteren benötigten Komponenten mit passenden handelsüblichen Verbindungskabeln an die entsprechenden Schnittstellen an. Beachten Sie die Pin-Belegung!
- Schließen Sie optional einen externen VGA-Monitor (16 : 9) mit einem handelsüblichen VGA-Kabel an der Buchse „VGA“ an. Die maximal mögliche Länge beträgt 15 m.
- Schließen Sie zuletzt die verriegelbare 4-polige Kleinspannungsbuchse des externen Netzteils an den 4-poligen DC-Einbaustiftstecker (+24 V - 1 A) auf der Geräterückseite an. Verbinden Sie das Netzteil mit dem Stromnetz.
- Der TouchMonitor startet und initialisiert das Betriebssystem. Nach kurzer Zeit ist das Gerät betriebsbereit.


DE

Anschlüsse

TouchMonitor TMR7

Extern:


Standard-VGA-Monitor 16 : 9



4-pol. Kleinspannungsstecker

VGA

24 V DC - 1 A




Extern:
USB-Maus
Wacom®-Grafik-Tablett

Pin-Belegung

„AES3 In 1“, „AES3 In 2“ (trafo-sym., 3-pol. XLR-F)

Pin: Funktion:

- 1 Schirm/Gehäuse
- 2 +, heiß
- 3 -, kalt



HINWEIS - Die AES3-Eingänge sind fest mit $110\ \Omega$ terminiert.

„AES3 Out 1“, „AES3 Out 2“ (trafo-sym., 3-pol. XLR-M)

Pin: Funktion:

- 1 Schirm/Gehäuse
- 2 +, heiß
- 3 -, kalt



„24 V - 1 A“ (4-pol. Kleinspannungsstiftstecker, Typ Binder 710)

Pin: Funktion:

- 1 - 2 +24 V DC/+12 V DC
- 3 - 4 0 V



DE

HINWEIS - Bei einer externen Stromversorgung ist eine externe Überstrombegrenzung auf 2 A zwingend vorzusehen!

„USB-A“

2 Full-Speed-USB-2.0-Anschlüsse für USB-Sticks (Lizenzabwicklung, Presets, etc), externe Computer-Maus oder Wacom®-Tablett.


DE

Pin-Belegung (Fortsetzung)

„VGA“ (15-pol. Sub-D-F)

Pin: Funktion:

1	R	Video-Signal
2	G	
3	B	
4 - 8	GND	
9	+5 V	
10 - 11	GND	
12	SDA	
13	H-sync	
14	V-sync	
15	SCI	



(Außenansicht der Einbaubuchse)

„GP IO“ (RJ-12-6P6C-Buchse)

Externe Steuerung der im Menü „Globales Tastenfeld“ definierten Funktionen. Die als „active low“ ausgelegten Eingänge sind gegen 0 V (Pin 1) zu schalten.


Pin: Funktion:

1	GND (0 V)
2 - 6	Funktion entsprechend der Definition im Menü



(Außenansicht der Einbaubuchse)

Blockdiagramm der GPIO-Schnittstelle



HINWEIS - Das VGA-Kabel soll nicht länger als 15 m sein!

„LAN“

RJ-45-Standard-Netzwerk-Anschluss (10/100 MBit)

Schnellstart

Inbetriebnahme

Bitte vergewissern Sie sich vor dem Anschließen der Stromversorgung, dass die folgenden Anschlüsse passend zu Ihrem Gerät (TM7, TMR7, TMR7 Smart, TM9) und zu Ihrer individuellen Installation vorgenommen wurden:

- Analoge und/oder digitale Audio-Eingangssignale (je nach Typ und Ausstattung Ihres Gerätes)
- Digitale Ausgänge (falls vorhanden)
- Optionaler externer VGA-Bildschirm (16 : 9) (nicht TMR7 Smart)
- Optionale USB-Maus
- LAN/Ethernet-Netzwerkanschluss (falls benötigt)
- Netzspannung

Nach dem Anlegen der Stromversorgung startet der TouchMonitor direkt sein Betriebssystem. Nach kurzer Zeit erscheint die Haupt-Bildschirmseite, das Gerät ist betriebsbereit.

Wir nehmen an, dass Sie Ihren TouchMonitor zum ersten Mal starten. An dieser Stelle sollten Sie einige globale Einstellungen zur Anpassung Ihres Gerätes an Ihr Audio-System vornehmen. Nach dieser kurzen Prozedur können Sie Ihr erstes Preset für Ihre Arbeit erstellen.

DE



HINWEIS - Die Abbildungen in den folgenden Abschnitten können Optionen zeigen, die auf Ihrem Gerät nicht verfügbar sind. Der Options-Umfang ist abhängig vom Typ Ihres Gerätes (TM7, TMR7, TMR7 Smart, TM9), von dessen Hardware-Konfiguration und von den auf dem Gerät freigeschalteten Lizenzen bzw. der auf dem Gerät installierten Software.


Anpassung des TouchMonitors an Ihr Audio-System

Die folgende Beschreibung führt Sie durch die wichtigsten Schritte der globalen Einstellungen, um einmalig den TouchMonitor für Ihr Audio-System zu konfigurieren. Diese Einstellungen bleiben beim Laden neuer Presets unverändert.

1. Falls nicht sichtbar, berühren Sie eine freie Stelle des Bildschirms zur Anzeige der Steuerleiste.
2. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste. Sie gelangen ins Menü-System, das **Hauptmenü** wird angezeigt.




2. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste. Sie gelangen ins Menü-System, das **Hauptmenü** wird angezeigt.



3. Berühren Sie die Taste **System**. Sie gelangen ins System-Menü, von dem das Untermenü **General** aktiviert ist (Taste ist in der Steuerleiste markiert).

4. Berühren Sie, falls erforderlich, die Taste **Menüsprache**. Wählen Sie in der rechten Hälfte des Menüs Ihre Sprache, die Auswahl wird auf der Taste **Menüsprache** angezeigt.

Die Umstellung auf die neue Sprache erfolgt nach Neustart.




5. Berühren Sie die Taste **Audio** im linken Bereich der Steuerleiste, um ins Untermenü **Audio** zu gelangen.



- Falls Ihr TouchMonitor eine definierte Referenzquelle benötigt, berühren Sie die Taste **Sync-Referenz** und wählen Sie die gewünschte Option in der rechten Hälfte des Menüs.

Info: Die Anzahl der verfügbaren Sync-Referenz-Quellen ist abhängig vom Gerätetyp und von Umfang und Art der installierten Audio-Schnittstellen.



- Berühren Sie die Taste **Uhr**, falls Sie das aktuelle Datum und die aktuelle Uhrzeit einstellen möchten. Berühren Sie die Taste **Zeit übernehmen** zum Starten der internen Uhr.





- Berühren Sie die Taste **Speichern**, um Ihre globalen Einstellung zu sichern. Das Gerät kehrt zurück in den normalen Anzeigemodus.

Erstellen eigener Presets

Presets enthalten die Einstellungen für Ihren Work-Flow. Sie können Audio-Gruppen erstellen, die auf bestimmte Eingänge zugreifen und eine oder mehrere Instrumente mit dieser Zuordnung enthalten. Ebenso können Sie Non-Audio-Gruppen erzeugen, die von Audio-Eingangssignalen unabhängige Instrumente enthalten, z. B. Uhren, Hardware-Statusinformationen oder ein Globales Tastenfeld.

Gehen Sie wie folgt vor, wenn Sie ein neues Preset erstellen möchten:

1. Falls nicht sichtbar, berühren Sie eine freie Stelle des Bildschirms zur Anzeige der Steuerleiste.
2. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste. Sie gelangen ins Menü-System, das **Hauptmenü** wird angezeigt.
3. Berühren Sie die Taste **Presets verwalten**. Sie gelangen ins Menü **Interne Presets**.
4. Berühren Sie die Taste **Neu**. Ein Preset mit einem editierbaren vorgegebenen Namen wird erstellt (siehe Abbildung unter 5., berühren Sie die Taste **Preset-Name** zur Änderung).




- Berühren Sie die Taste **Audio neu** zur Erstellung der ersten Audio-Gruppe.




- Die Taste **Modus** erscheint und ist markiert. Wählen Sie Ihren Kanalmodus in der rechten Hälfte des Menüs.

i Die Anzahl der Modi ist abhängig vom Gerätetyp und von den aktiven Software-Lizenzen.



- Falls die Lizenz **Loudness and SPL display** (SW20002) aktiviert oder das Gerät ein TMR7 Smart ist, erscheint das Untermenü **Loudness-Typ**. Wählen Sie Ihren bevorzugten Loudness-Typ.




9. Links erscheint das Feld **Instrumente** und rechts eine Liste der verfügbaren Instrumente.

Info: Die Anzahl der Instrumente ist abhängig von den aktivierten Software-Lizenzen.



10. Berühren Sie jeweils die Tasten der gewünschten Instrumente. Die Auswahl erscheint als Piktogramm im Feld **Instrumente**.




11. Wenn Sie mit der Auswahl fertig sind, berühren Sie die Taste **fertig**. Sie kehren ins Menü **Preset** zurück.



Info: Das Menü **Preset** zeigt nun die gerade erstellte Audio-Gruppe mit einem kleinen farbigen Dreieck in der linken oberen Ecke. Im Normalbetrieb sind alle Instrumente dieser Gruppe mit diesem Dreieck markiert. Bei mehreren Gruppen erleichtert die Farbmarkierung die Identifizierung, zu welcher Gruppe ein Instrument gehört.


12. Berühren Sie die Taste **View**. Das angezeigte Untermenü dient der Anordnung der Instrumente auf dem Bildschirm. Die definierten Gruppen mit ihren Instrumenten erscheinen in der linken Hälfte des Menüs (nächstes Bild).






Das Untermenü View ist ein umfangreicher Editor zur Positionierung und Skalierung der im aktuellen Preset definierten Instrumente. Alle Instrumente, die Sie im Normalbetrieb sehen möchten, müssen hier positioniert werden.

13. Berühren Sie ein Piktogramm. Es wird in der linken oberen Ecke der Bildschirm-Grafik platziert.




14. Benutzen Sie die Tasten **Position** und **Größe** zur Platzierungs- und Größenänderung.




15. Verfahren Sie ebenso mit den anderen Piktogrammen.


Sollten sich Instrumente überlagern, erscheint eine Warnung.
Verschieben Sie das Piktogramm mit den Tasten Position und Größe an eine freie Stelle.



16. Wenn das Bildschirm-Layout Ihren Anforderungen entspricht (Sie können Instrumente auch drehen), berühren Sie die Taste **Speichern** unten im rechten Bereich der Steuerleiste.



17. Sie gelangen zurück in den Normalbetrieb. Auf dem Bildschirm sehen Sie das neu erstellte Preset mit den ausgewählten Instrumenten in der definierten Anordnung.



Arbeiten mit Instrumenten und Presets

Im Normalbetrieb zeigt der TouchMonitor die Instrumente und das Bildschirm-Layout entsprechend der Definition im ausgewählten Preset. Sie können mit den Tasten der Steuerleiste ein gewähltes Instrument steuern oder ein neues Preset laden.


Info Falls die Steuerleiste nicht sichtbar ist, berühren Sie einfach den Bildschirm. Die Steuerleiste wird zur Wahl der gewünschten Funktion für einige Sekunden angezeigt.

Gehen Sie wie folgt vor, wenn Sie die Funktionen eines Instrumentes nutzen möchten:


1. Berühren Sie die Fläche des Instruments auf dem Bildschirm. Es erhält den Fokus. Im linken Bereich der Steuerleiste erscheinen die speziellen Funktionen des fokussierten Instruments.
Info Das aktuell gewählte Instrument ist mit einem farbigen Rahmen entsprechend der Farbmarkierung zur Identifizierung des Instruments versehen.

2. Wählen Sie die gewünschte Funktion.


Info Bei mehr als 6 Funktionen berühren Sie die Taste **mehr**. Falls eine Funktionstaste eine weitere Funktionsebene öffnet, gelangen Sie mit der Taste **Schließen** wieder zurück in die vorherige Ebene.



Gehen Sie wie folgt vor, wenn Sie ein Preset laden möchten:




1. Berühren Sie die Taste **Preset laden** im rechten Bereich der Steuerleiste. Eine Liste mit verfügbaren Presets wird angezeigt.



2. Berühren Sie die Taste des gewünschten Presets.

Das aktuell gewählte Preset ist mit grün als aktiv markiert. Im Normalbetrieb erscheint der Name des aktiven Presets in der rechten unteren Ecke des Bildschirms.
3. Das gewählte Preset wird geladen. Das Gerät kehrt automatisch in den Normalbetrieb zurück und zeigt das neu gewählte Preset.



- Für die in den Bildern gezeigten Funktionen wie Loudness oder Vektorschop ist je nach Gerätetyp (außer TMR7 Smart) die Aktivierung weiterer Software-Lizenzen erforderlich.

Mitgelieferte Presets

Der beigelegte USB-Stick enthält 16 vordefinierte Presets für den TouchMonitor TMR7, die einen Querschnitt durch die unterstützten Anwendungsbereiche und Standards darstellen. Mit Hilfe dieser Presets können Sie das Gerät unmittelbar in Betrieb nehmen und nach Bedarf eigene Voreinstellungen definieren. Für die OEM-Version stehen alle Presets auch für den vertikalen Betrieb zur Verfügung. Screenshots und die wichtigsten Merkmale sind auf den nächsten Seiten dargestellt.

Presets vom USB-Stick laden

1. Berühren Sie den Bildschirm und dann **Preset laden** im rechten Teil der Steuerleiste am unteren Bildschirmrand.
2. Berühren Sie **extern**. Die verfügbaren Presets werden angezeigt.
3. Berühren Sie das Preset Ihrer Wahl. Dieses wird geladen und steht nach kurzer Zeit im Normalbetrieb zur Verfügung.




HINWEIS - Beachten Sie bitte, dass der TouchMonitor TMR7 nur die Presets anzeigen kann, deren Hardware- und Instrumenten-Setup mit der Hardware und den aktivierten Lizenzen Ihres Gerätes übereinstimmen. Bei bestehenden Unterschieden erfolgt eine Fehlermeldung und die Anzeige wird abgelehnt.



Eine Beschreibung der in den einzelnen Presets verwendeten Instrumente sowie nützliche Hinweise zur schnellen Interpretation der abgelesenen Ergebnisse finden Sie auf der internen Hilfeseite des jeweiligen in den Fokus gesetzten Instrumentes (berühren Sie **Hilfe** rechts unten in der Steuerleiste) oder unter dem Stichwort **Funktionsbeschreibung/Instrumente** im Manual auf dem USB-Stick.

DEFAULT




Eingang: AES3 1

Program Meter Skala: Dig60: 0..-60 dB (-60 bis 0 dBFS)

Instrumente: Program Meter (PPM-Modus), Correlator

HINWEIS - Dieses Preset ist fest im System verankert und dient der Sicherstellung der grundlegenden Anzeigefunktionalität. Es kann nicht editiert werden. Auf die Betätigung der Preset-bezogenen Tasten erfolgt keine Reaktion.

ATSC+PPM (nur darstellbar mit aktivierter Lizenz SW20002)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: ATSC A/85

Program Meter Skala: Dig60: 0..-60 dB (-60 bis 0 dBFS)

Instrumente: Program Meter (PPM-Modus), Correlator, Vectorscope, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

Tasten: Loudness Num Tastenfeld: Start, Stop, Reset Loudness

DE

DUAL ATSC (nur darstellbar mit aktivierter Lizenz SW20002 und SW20006)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: ATSC A/85

Program Meter Skala: Dig60: 0..-60 dB (-60 bis 0 dBFS)

Instrumente: Program Meter (PPM-Modus), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Gruppe: Stereo 2

Eingang: AES3 2

Loudness: ATSC A/85

Program Meter Skala: Dig60: 0..-60 dB (-60 bis 0 dBFS)

Instrumente: Program Meter (PPM-Modus), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Global Keyboard: Tasten: Start, Stop, Reset

DUAL EBU (nur darstellbar mit aktiver Lizenz SW20002 und SW20006)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: EBU R128

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Modus), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Gruppe: Stereo 2

Eingang: AES3 2

Loudness: EBU R128

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Modus), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Global Keyboard: Tasten: Start, Stop, Reset

DE

DUAL+RTA EBU (nur darstellbar mit aktivierten Lizenzen SW20002 und SW20003)



Gruppe: Stereo 1
 Eingang: AES3 1
 Loudness: EBU R128
 Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)
 Instrumente: Program Meter (PPM, Headroom -13 dB, Skalenmarke -18 dBTP), RTA (1/3-Oktav, linear, fast), Correlator, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)
 Tasten: Loudness Num Tastenfeld: Start, Stop, Reset Loudness

Gruppe: Stereo 2
 Eingang: AES3 2
 Loudness: EBU R128
 Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)
 Instrumente: Program Meter (PPM, Headroom -13 dB, Skalenmarke -18 dBTP), RTA (1/3-Oktav, linear, fast), Correlator, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)
 Tasten: Loudness Num Tastenfeld: Start, Stop, Reset Loudness


MC BBC EBU (nur darstellbar mit aktivierten Lizenzen SW20002 und SW20006)



Gruppe: Stereo 1
Eingang: AES3 1
Loudest: EBU R128
Program Meter Skala: BR IIa: 7..1
Instrumente: Moving Coil Meter (PPM-Modus Dual+M/S vertikal), Vectorscope, Loudest Num (M, S, I, LRA, TPmax, Mmax, Smax)

Gruppe: Stereo 1
Eingang: AES3 1
Loudest: EBU R128
Program Meter Skala: Loudest
Instrumente: Moving Coil Meter (Loudest-Modus Dual)

MC VU ATSC (nur darstellbar mit aktivierten Lizenzen SW20002, SW20003 und SW20006)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: ATSC A/85

Program Meter Skala: VU digital

Instrumente: Moving Coil Meter (VU-Modus Stereo Horizontal), Vectorscope, RTA (1/3-Oktav, linear, fast), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

PPM+VSC ARD



DE

Gruppe: Stereo 1

Eingang: AES3 1

Program Meter Skala: ARD9: +9..-60 dB (-60 bis +9 dB)

Instrumente: Program Meter (PPM-Modus), Correlator, Vectorscope

Global Keyboard:

Tasten im Preset-Modus: PPM BBC, PPM NORDIC, TRUE PEAK (Damit ist schneller Wechsel zu den Presets 9, 10 und 16 möglich, die gleichartig konfiguriert sind und sich nur durch die PPM-Skala unterscheiden)

PPM+VSC BBC



Gruppe: Stereo 1

Eingang: AES3 1

Program Meter Skala: BR IIa: 7..1

Instrumente: Program Meter (PPM-Modus), Correlator,
Vectorscope

Global Keyboard:

Tasten im Preset-Modus: PPM ARD, PPM
NORDIC, TRUE PEAK (Damit ist schneller
Wechsel zu den Presets 8, 10 und 16 möglich,
die gleichartig konfiguriert sind und sich nur
durch die PPM-Skala unterscheiden)

PPM+VSC NORDIC



Gruppe: Stereo 1

Eingang: AES3 1


Program Meter Skala: Nordic: +12..-42 dB

Instrumente: Program Meter (PPM-Modus), Correlator,
Vectorscope

Global Keyboard:

Tasten im Preset-Modus: PPM ARD, PPM BBC, TRUE PEAK (Damit ist schneller Wechsel zu den Presets 8, 9 und 16 möglich, die gleichartig konfiguriert sind und sich nur durch die PPM-Skala unterscheiden)

R128+PPM (nur darstellbar mit aktivierter Lizenz SW20002)



Gruppe: Stereo 1

Eingang: AES3 1


Loudness: EBU R128

Program Meter Skala: Dig60: 0..-60 dB (-60 bis 0 dBFS)

Instrumente: Program Meter (PPM-Modus), Correlator, Vectroscope, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

Tasten: Loudness Num Tastenfeld: Start, Stop, Reset
Loudness


ST ATSC (nur darstellbar mit aktivierter Lizenz SW20002)



- Gruppe: Stereo 1
- Eingang: AES3 1
- Loudness: ATSC A/85
- Instrumente: Vectorscope, LRA (MagicLRA + I-Modus),
Loudness Num (M, S, I, LRA, TPmax, Mmax,
Smax)
- Tasten: Loudness Num Tastenfeld: Start, Stop, Reset
Loudness


DE

ST EBU (nur darstellbar mit aktiver Lizenz SW20002)



- Gruppe: Stereo 1
Eingang: AES3 1
Loudness: EBU R128
Instrumente: Vectorscope, LRA (MagicLRA + I-Modus),
Loudness Num (M, S, I, LRA, TPmax, Mmax,
Smax)
Tasten: Loudness Num Tastenfeld: Start, Stop, Reset
Loudness

ST+PFL ATSC (nur darstellbar mit aktivierte Lizenzen SW20002 und SW20006)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: ATSC A/85

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Classic-Modus), Vector-
scope, Loudness Sum (M, S), Loudness Num
(I, TPmax)

Gruppe: Stereo 2

Eingang: AES3 2


Loudness: ATSC A/85

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Classic-Modus), Loud-
ness Num (I, TPmax)

Global Keyboard: Tasten: Start, Stop, Reset

ST+PFL EBU (nur darstellbar mit aktivierten Lizenzen SW20002 und SW20006)



Gruppe: Stereo 1

Eingang: AES3 1

Loudness: ATSC A/85

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Classic-Modus), Vector-
scope, Loudness Sum (M, S), Loudness Num
(I, TPmax)

Gruppe: Stereo 2

Eingang: AES3 2

Loudness: ATSC A/85

Program Meter Skala: TP60: +3..-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Classic-Modus, Skalen-
marke -18 dBTP), Loudness Num (I, TPmax)

Global Keyboard: Tasten: Start, Stop, Reset

TRUE PEAK



Gruppe: Stereo 1

Eingang: AES3 1

Program Meter Skala: TP60: +3,-60 dB (-60 bis +3 dBTP)

Instrumente: Program Meter (PPM-Modus), Correlator,
Vectorscope

Global Keyboard:

Tasten im Preset-Modus: PPM ARD, PPM BBC, PPM NORDIC (Damit ist schneller Wechsel zu den Presets 8, 9 und 10 möglich, die gleichartig konfiguriert sind und sich nur durch die PPM-Skala unterscheiden)

Software-Module (Lizenz-Abwicklung)

Der TouchMonitor besitzt eine modulare Software, die es dem Anwender gestattet, seinem Gerät nach Bedarf jederzeit neue Funktionen und Instrumente hinzuzufügen. Die Menüseite **Lizenzen** dient zur Ansicht der aktuell im TouchMonitor installierten Software-Lizenzen und zum Erwerb neuer Lizenzen. Instrumente und Funktionen, die bereits aktiviert wurden, sind mit dem Vermerk **installiert** gekennzeichnet. Für Instrumente und Funktionen, die noch nicht aktiviert wurden, steht die Taste **Lizenz erwerben** zur Verfügung. Im Menü **Lizenzen** finden Sie nur die Lizenz-Optionen, die zum Zeitpunkt der Veröffentlichung der auf dem Gerät installierten Software-Version erhältlich waren und für Ihr Gerät zur Verfügung gestellt wurden.



HINWEIS - Einige Lizenzen erfordern die vorherige Aktivierung weiterer Lizenzen, um sie nutzen zu können. Beachten Sie bitte die entsprechenden Hinweise bei der Lizenzbestellung.



HINWEIS - Die Abbildungen in den folgenden Abschnitten können Lizenzen zeigen, die auf Ihrem Gerät, bedingt durch den Typ (TM7, TMR7, TM9) und deren Hardware-Konfiguration, nicht zur Verfügung stehen.

Gehen Sie wie folgt vor, wenn Sie Lizenzen erwerben möchten:

1. Stecken Sie einen USB-Stick in einen der USB-Anschlüsse auf der Geräterückseite.
2. Falls nicht sichtbar, berühren Sie eine freie Stelle des Bildschirms oder ein Instrument zur Anzeige der Steuerleiste.



3. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste. Sie gelangen ins Menü-System, das **Hauptmenü** wird angezeigt.



4. Berühren Sie die Taste **Lizenzen**. Die verfügbaren Lizenzen werden angezeigt, die aktivierten sind mit **installiert** markiert.




5. Berühren Sie die entsprechenden Tasten der Lizenzen, die Sie erwerben möchten.



6. Berühren Sie die Taste **Bestellung exportieren** im linken Bereich der Steuerleiste.

! Der TouchMonitor erzeugt eine Ordnerstruktur **/rtw/licence** auf dem USB-Stick. Eine verschlüsselte Lizenzanforderungsdatei (nnn_nn.lrf) abhängig von der individuellen Seriennummer der Hardware wird in diesen Ordner gespeichert.

7. Warten Sie, bis die Menüseite den erfolgreichen Export der Lizenzanforderungsdatei bestätigt.



8. Berühren Sie die Taste **fertig**. Sie gelangen wieder ins Hauptmenü.

! Mit eingestecktem USB-Stick erscheinen rechts weitere Tasten zum Export oder Import einzelner Presets oder der globalen Einstellungen auf den bzw. vom USB-Stick.



9. **Warten Sie ein paar Sekunden, um die Lizenzanforderungsdatei nicht zu beschädigen!**

Entfernen Sie erst dann den USB-Stick vom TouchMonitor, stecken Sie ihn in Ihren Computer und laden Sie die Lizenzanforderungsdatei direkt im RTW-Shop hoch: <https://www.rtw.com/de/shop.html>.

Sie können die Datei auch an Ihren Händler senden.

! Abweichend von dem unter Punkt 6 genannten Verzeichnis kann die Datei in Einzelfällen auch im Verzeichnis **/rtw/tm7h/licence** bzw. **/rtw/tm9h/licence** abgelegt sein.

10. Nach Erwerb der Lizenz erhalten Sie eine neue Datei (nnn_nn.lf) mit der darin integrierten Lizenzanforderungsdatei.

! Die zurückgegebene Datei ist nur für das Gerät gültig, auf dem die Lizenzanforderungsdatei erzeugt wurde.

11. Die Lizenzdatei (nnn_nn.lf) muss in den gleichen Ordner auf dem USB-Stick gespeichert werden wie die Lizenzanforderungsdatei.


12. **Melden** Sie den USB-Stick ordnungsgemäß vom Computer-System **ab!** Ziehen Sie ihn **erst dann** vom Computer ab!

ACHTUNG! - Die Abmeldung vom Computer ist erforderlich, um eine Beschädigung der kopierten Datei zu vermeiden!

13. Entfernen Sie den USB-Stick von Ihrem Computer und stecken Sie ihn erneut in einen der USB-Anschlüsse des TouchMonitor.


14. Öffnen Sie das Menü **Lizenzen** wie in den Schritten 2. bis 4.

15. Die Lizenzdatei wird registriert. Im linken Bereich der Steuerleiste erscheint die Taste **Lizenzen importieren**.



16. Berühren Sie die Taste **Lizenzen importieren**, um die Datei auf das System zu übertragen.

17. Wenn der Import abgeschlossen ist, starten Sie den TouchMonitor neu. Berühren Sie dazu die Taste **Zurück**.



18. Das lizenzierte Instrument oder die lizenzierte Funktion ist nun permanent verfügbar.

19. Wenn Sie einen TM7 oder TM9 von TC electronic® mit Lizenz SW20021 in ein RTW-Gerät konvertiert haben, führen Sie ein Software-Update (auch mit gleichlautender Firmware) durch. Anschließend startet das Gerät mit dem RTW-Boot-Screen.

Software-Update

Um Ihrem TouchMonitor nach Bedarf jederzeit neue Funktionen und Instrumente hinzufügen zu können, sollten Sie in regelmäßigen Abständen die System-Software (Firmware) aktualisieren. Es stehen immer nur die Optionen und Lizenzen im Gerät zur Verfügung, die zum Zeitpunkt der Veröffentlichung der installierten Software-Version für Ihr Gerät erhältlich waren.

Software-Updates erhalten Sie über Ihren Vertriebspartner oder im Download-Bereich auf unserer Web-Seite (<https://www.rtw.com/de/support/manuals-software.html>). Klicken Sie dort auf „Audio-Monitor“ und dann auf die Option, die Ihrem Gerätetyp entspricht.



Gehen Sie wie folgt vor, wenn Sie Ihre Software aktualisieren:

1. Kopieren Sie die Update-Datei (rtw-tm-fw-n-n.bin; n-n: Versionsnummer) ins Hauptverzeichnis eines USB-Sticks.
2. **Melden** Sie den USB-Stick ordnungsgemäß vom Computer-System **ab!** Ziehen Sie ihn **erst dann** vom Computer ab!

ACHTUNG! - Die Abmeldung vom Computer ist erforderlich, um eine Beschädigung der kopierten Datei zu vermeiden!

3. Entfernen Sie den abgemeldeten USB-Stick von Ihrem Computer und stecken Sie ihn in einen der USB-Anschlüsse des TouchMonitor.



4. Falls nicht sichtbar, berühren Sie eine freie Stelle des Bildschirms oder ein Instrument zur Anzeige der Steuerleiste.
5. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste, dann im **Hauptmenü** die Taste **System**.
6. Berühren Sie die Taste **Spezial**. Die zusätzliche Taste **Firmware Update starten: rtw-tm-fw-n-n** wird angezeigt.
7. Berühren Sie die Taste. Das ca. 10-minütige Update wird gestartet.



8. Wenn das Update abgeschlossen ist, wird der TouchMonitor automatisch neu gestartet.
9. Berühren Sie die Taste **Menü** im rechten Bereich der Steuerleiste, dann im **Hauptmenü** die Taste **Info-Menü**.
10. Überprüfen Sie die **Software-Version** (dort sollte die Bezeichnung der Update-Datei erscheinen), die Seriennummer und die Modellbezeichnung.

DE

Technische Daten (Auszug)

System

Allgemein

Spannungsversorgung: +24 V DC (2-A-Überstrombegrenzung ist zwingend vorzusehen)
Verlustleistung: ca. 8,5 W
Stromaufnahme: 1 A Nennstrom, 2,5 A Einschaltstrom (10 µsec.)
Display: 7"-TFT-Touch-Screen 16 : 9 (800 x 480 Pixel)
Anschlüsse:
Farben, 60 Hz, zum Anschluss eines handelsüblichen 16 : 9
VGA-Monitors, Seitenverhältnis 4 : 3 intern einstellbar
1 x 4-pol. verriegelbarer Kleinspannungsstecker Typ 710 (DC)
2 x USB A; USB-2.0-Full-SpeedAnschluss für:

- USB-Sticks zur Lizenz-Abwicklung und für Preset-Export und -Import und Software-Updates
- Externe Computer-Maus oder Wacom®-Grafik-Tablett

1 x GPIO (RJ-12-6P6C, zur Fernsteuerung definierter Funktionen)
1 x LAN (RJ-45)
2 x XLR-F (2 x AES3 In)
2 x XLR-M (2 x AES3 Out)

Abmessungen (B x H x T):

- TMR7: 198 x 139,5 (163) x 46 (95) mm (mit Tischfuß)
- TMR7OEM: 188 x 109 x 45 mm

Gewicht: ca. 2,7 kg (Tischgerät ohne Netzteil)
Arbeitstemperatur: im Bereich von +5° bis +40° C

Funktionen (mit allen verfügbaren Lizzenzen aktiviert)

- Steuerung per Finger, mit Maus oder Tablett
- Instrumente frei skalierbar und positionierbar
- Multiformat-4-Kanal-PPM (2-Kanal Stereo, 2 x 2-Kanal Stereo, Einzelkanal, Mehrkanal bis zu 4 Kanäle)
- Loudness-Meter: EBU R128, ITU BS.1770-4/1771-1, ATSC A/85, ARIB, OP-59, AGCOM, CALM Act, LEO(M), TASA, SAWA und anwenderspezifisch, SPL-Meter
- Loudness-Messzeitsteuerung
- Loudness-Range-Instrument (LRA)
- Logging-Data-Server mit Logging- und Chart-Instrument
- Moving-Coil (BR-, VU-, Loudness-, BBC-Modus)
- Gain-Reduction-Instrument
- Stereo-Korrelator
- 31-, 61- und 122-Band Spektrum-Analysator
- 2-Kanal Audio-Vektorschop (4 Instanzen möglich)
- AES3-Statusmonitor
- Numerische Anzeigen, Timecode

Digitale Eingänge

Eingänge: 2 AES3 Eingänge (trafosymmetrisch, 110 Ohm), 2 x XLR-F-Einbaubuchse, 3-polig
Abtastraten: 44,1, 48, 96 kHz, Taktanbindung über digitalen Signal-Eingang oder intern

Digitale Ausgänge

Ausgänge: 2 AES3-Ausgänge, 2 x XLR-M-Einbaubuchse, 3-polig
Abtastraten: referenziert auf digitalen Eingang oder internen Takt

Basis-PPM (Standard-Software)

Allgemein

Eingangsquellen:	digital über XLR-Audio-Schnittstelle (AES3)
4-Kanal-Peakmeter:	2-Kanal Stereo, 2 x 2-Kanal Stereo, Einzelkanal, Mehrkanal bis zu 4 Kanäle
Anzeigen:	<ul style="list-style-type: none">▪ Spitzpegel▪ Peak-Hold▪ Numerischer Wert der Anzeige
Funktionen:	<ul style="list-style-type: none">▪ Gain (+20 dB, +40 dB, je nach gewähltem Standard)▪ Peak-Hold ein/aus, Memory, Reset

Digitale Peakmeter

Wortbreite:	24 Bit
Digitale Skalen:	<ul style="list-style-type: none">▪ TP60: +3 .. -60 dB▪ Dig60: 0 .. -60 dB▪ DIN5: +5 .. -50 dB,▪ Nordic: +12 .. -42 dB,▪ BR IIa: 7 .. 1 (British),▪ BR IIb: +12 .. -12 dB (British),
Headroom/Headr. Ref:	einstellbar im Bereich von 0 bis -20 dB in 1-dB-Schritten
Arbeitsbereich:	einstellbar im Bereich von 0 bis -20 dB in 1-dB-Schritten
Integrationszeit (Attack):	wie Standard oder wählbar: Sample, 20 ms, 10 ms, 1 ms, 0,1 ms
	British-Skalen zusätzlich auch 150 ms wählbar
Gain:	+20 dB, +40 dB, je nach gewähltem Standard
Hochpass-Filter:	Off, 5 Hz, 10 Hz, 20 Hz
Peak-Hold-Anzeige:	1 s, 2 s, 4 s, 10 s, 20 s, 30 s, manueller Reset oder aus
Over-Anzeige-Dauer:	1 s oder manuell
PPM-Over-Schwelle:	Full Scale, Full Scale -1LSB, Full Scale -2LSB, -0,1 dBFS, -0,5 dBFS, -1 dBFS, -2 dBFS, -3 dBFS
PPM-Over-Ansprechzeit:	1 bis 15 Samples
PPM-Over-Wortbreite:	16 bis 24 Bit, einstellbar
True-Peak-Over-	
Anspruchschwelle:	-1.0 dBTP, -2.0 dBTP, -3.0 dBTP, -4.0 dBTP

Audio Vectorscope

Betriebsart:	2-Kanal
Inputs:	L/R (Stereo-Signal der innerhalb der Audio-Gruppe definierten Eingangskanäle)
AGC:	fast/slow
Darstellung (Grid):	L/R oder M/S

AES3-Status-Monitor

Anzeige:	<ul style="list-style-type: none">▪ Kanal-Daten in Klartext, Hexadezimal- oder Binär-Darstellung▪ Kanal einstellbar▪ Audio-Bit-Aktivität▪ Hardware-Status
----------	--

Global Keyboard

Globales Tastenfeld zur simultanen Steuerung definierter Funktionen in verschiedenen Instrumenten und Preset-Aufruf, ermöglicht auch die Steuerung über die GP IO-Schnittstelle

Gain Reduction

Anzeige:	1 Bargraph für Mono- und Stereo-Formate, bis zu 4 Bargraphen im Mehrkanal-Modus
Eingang:	Daten-Stream über TCP/IP und LAN-Schnittstelle
Eingangsrouting:	Auswahl der extern zur Verfügung gestellten Streams
Marker:	einstellbarer Schwellwert zur Definition des oberen und unteren Bereiches
Farben:	32 Farben für jeden Bargraph-Bereich

Die vollständigen technischen Daten finden Sie im TouchMonitor TMR7 Datenblatt (erhältlich auf der Produktseite auf der RTW-Webseite oder auf dem mitgelieferten USB-Stick als Teil des Manual-Inhalts).

DE

CE-Konformitätserklärung

EG-Konformitätserklärung | Richtlinie 2004/108/EG und Richtlinie 2006/95/EG

Die RTW GmbH & Co. KG, Am Wassermann 25, 50829 Köln, Deutschland, erklärt in alleiniger Verantwortung, dass die Produkte der

RTW TouchMonitor TMR7 Serie
(OEM-Gerät/Tischgerät)

auf die sich diese Erklärung bezieht, mit den folgenden Normen bzw. normativen Dokumenten übereinstimmt:

EMV 2004/108/EG

EN 61000-6-3: 2012-11 Emissions:

EN 55022: 2011-12 Class B, gestraht

EN 55022: 2011-12 Class B, leitungsgeführt

EN 61000-6-1: 2007-12-01 Immunity:

EN 61000-4-2 + A1 + A2: 2002-02-01

EN 61000-4-4: 2005-09-01

EN 61000-4-5: 2007-08-01

Sicherheit 2006/95/EG

EN 60950-1: 2007-01-01

Geprüft und dokumentiert von nachfolgend aufgeführten Firmen:

RTW GmbH & Co.KG, Köln

Datum und Unterschrift des Verantwortlichen:

2013-03-14

i. A. 

RoHS-Konformitätserklärung

RoHS-Konformitätserklärung für TMR7 | Richtlinie 2011/65/EU

Die RTW GmbH & Co. KG, Am Wassermann 25, 50829 Köln, Deutschland, erklärt in alleiniger Verantwortung, dass die Produkte der

RTW TouchMonitor TMR7 Serie

bestehend aus den Komponenten:

- TMR7 (TMR7 mit digitaler Audioschnittstelle im Tischgehäuse)
- TMR7OEM (TMR7 mit digitaler Audioschnittstelle, OEM-Gerät)
- TM7-MA3U (Montageadapter: OEM in 19"/3HE/42TE)
- TM7-MAVID (Montageadapter: OEM in 19"-Video-Racks)
- TM7-MADT (Montageadapter: OEM in Tischgehäuse)


auf die sich diese Erklärung bezieht, mit den Vorschriften der Richtlinie 2011/65/EU des Europäischen Parlamentes und des Rates vom 8. Juni 2011 zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten übereinstimmt.

Geprüft und dokumentiert von nachfolgend aufgeführten Firmen:

RTW GmbH & Co.KG, Köln

Datum und Unterschrift des Verantwortlichen:

24.04.2017 i. A.



CE und RoHS von Zulieferfirmen

Weitere Komponenten der TouchMonitor TMR7-Geräte stammen von Zulieferfirmen, die jeweils die CE- und RoHS-Konformität für ihre Produkte erklären:

- 1178-R (Netzteil 100 - 240 V AC/24 V DC, 2,71 A)
Zulieferer: Dehner-Elektronik
Hersteller: Adpater Technology Co., Ltd.
CE-Zertifikat Nr. T150115D02-E
RoHS-Konformität wird zusammen mit der CE-Erklärung bestätigt.
UL-Reference TH/SPC-1411065-SPC
- Beiliegender USB-Stick
Zulieferer: Blue Chili
Hersteller:
CE-Konformität Nr. E0700256
RoHS-Konformität Nr. R0808179

Lizenzen der implementierten Software

Die Produkte der TouchMonitor 7“ und 9“ Serien umfassen neben der Hardware ein Softwarepaket, das Programme mit unterschiedlichen Lizenzen beinhaltet. Ausführliche Informationen und die Lizenztexte dazu finden Sie im **Info**-Menü des Gerätes (-> **Menü** -> **Info** -> **Lizenz-Informationen**) oder in der ausführlichen Bedienungsanleitung, die sich auf dem beigefügten USB-Stick befindet. Im folgenden eine kurze Übersicht:

1. Software aus der Urheberschaft der RTW GmbH & Co.KG.

Diese Software darf nur zum bestimmungsmäßen Gebrauch des Gerätes verwendet werden (Applikation, DSP-Programme, Bootloader). Diese Software ist Eigentum der RTW GmbH & Co.KG und unterliegt dem deutschen und dem internationalen Urheberrecht.

2. Open Source Software, die unter der GPL oder LGPL der Free Software Foundation (FSF) steht.

3. Open Source Software, die unter der LGPL der Free Software Foundation (FSF) steht, aber spezifische Ausnahmeregelungen hat.

4. Software, die unter der MIT-Lizenz steht.

5. Spezielle Lizenzen

6. Weitere Lizenz-Hinweise

7. Angebot Quellcode / GPL

Die im Produkt TouchMonitor 7“ und 9“ enthaltene Software enthält urheberrechtlich geschützte Software, die unter der GPL lizenziert ist. Eine Kopie dieser Lizenz ist in diesem Dokument unten enthalten. Sie können den vollständigen korrespondierenden Quellcode für einen Zeitraum von drei Jahren nach unserer letzten Lieferung dieses Produkts von uns erhalten, indem Sie uns eine E-Mail an support@rtw.com senden. Dieses Angebot gilt für alle, die diese Informationen erhalten haben.

8. Keine Gewährleistung GPL

Köln, 20. November 2019

DE

Der Startbildschirm des TouchMonitor enthält je nach Version ein bearbeitetes Bild, dass auf der Fotografie „Cologne_CathedralNight-6.jpg“ von Lukasz Kryger, Edingburgh, Scotland, basiert. Die Bilder stehen unter der Creative Commons Attribution 2.0 Generic License (http://commons.wikimedia.org/wiki/File:Cologne_Cathedral-Night-6.jpg, <http://creativecommons.org/licenses/by/2.0/deed.de>).

RTW GmbH & Co. KG

Am Wassermann 25 | 50829 Köln | Germany

Phone: +49 221.70 913-0 | Fax: +49 221.70 913-32

Internet: www.rtw.com | E-Mail: rtw@rtw.com





Quick Start Guide

TouchMonitor TMR7 Series

EN

Software Version 8-02 and higher | 11.2019



Quick Start Guide
for

RTW TouchMonitor TMR7 Series

Manual Version: 3.0
Issued: 20.11.2019
Software Version: 8-02 and higher (11.2019)

© **RTW** 11/2019 | Technical changes without prior notice!

RTW GmbH & Co. KG
Am Wassermann 25 | 50829 Köln | Germany
Fon +49 221. 70 913-0 | Fax +49 221. 70 913-32
rtw@rtw.com | www.rtw.com

WEEE Reg.-no.: DE 90666819

RoHS Conformity: These instruments comply with and fall under category 9 Monitoring and control equipment of the regulations of the Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment of the European Parliament and Council from June 8th, 2011.



Please carefully **read** the safety instructions, **understand** them and **act** as requested to prevent any hazards or not to violate any laws.

Please note:

The external power supply is UL Listed for CAN/US, model ATS 065T-P/A240, manufactured by Adapter Technology Co Ltd. (RTW 1178-R), Class II double insulated, rated: Input: 100 - 240 V, 47 - 63 Hz, 1 A max. Output: 24 Vd.c., 2.71 A, 65 W

The figures in this operating manual are carefully created and are used to illustrate the descriptions. However, they may differ a little bit from the displays of your unit.

The current version of this manual and the available firmware/firmware updates can be found under Audio Monitors/TouchMonitor TMR7 in the download area of our web site (login page):
<https://www.rtw.com/en/support/manuals-software.html>.

The package contains a USB flash device source by a third party company. The device is certified by Shenzhen BSE Technology Co., Ltd. to be CE conform (E07002566) and RoHS compliant (R0808179).

A detailed RoHS declaration of conformity about TouchMonitor TMR7 series will be found in the appendix.

Safety Instructions

The following symbols may be marked on the panels or covers of equipment or module and are used in this manual with these terms:

WARNING!

This symbol alerts you to a potentially hazardous condition, such as the presence of dangerous voltage that could pose a risk of electrical shock. Refer to the accompanying Warning Label or Tag, and exercise extreme caution.

ATTENTION!

This symbol alerts you to important operating considerations or a potential operating condition that could damage equipment. If you see this marked on equipment, consult the operating manual for precautionary instructions.

NOTE

This symbol points your attention to specific characteristics that are no malfunctions.

Important Safety Instructions

- Read these instructions. Study carefully and understand all safety and operating instructions before you install and operate the unit!
- Keep these instructions. Keep all safety and operating instructions for future reference!
- Heed all warnings on the unit and in the safety and operating instructions before you install and operate the unit!
- Follow all instructions to ensure against injury to yourself and damage to the unit or other objects connected to the unit.

To prevent possible electrical shock, death, fire, injuries and malfunctions, use this product only as specified.

Only use attachments and accessories specified by the manufacturer. The units of the TouchMonitor series are designed for indoor use only and may only be operated with a power supply unit provided for it.

 **WARNING!**

Always follow the safety precautions below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire, or other hazards. These precautions include, but are not limited to, the following:

- Do not open the housing. Inside, there are no user-serviceable parts. Any necessary servicing shall be performed by a properly qualified technician.
- Do not attempt to repair any part of the unit. Repairs shall only be carried out by qualified personnel.
- Never remove any parts from the unit and do not make any modifications to the unit without the express written consent of RTW. Modifications can cause both safety hazards and affect the unit's conformity and certifications.
- Only use the power cord and power supply specified for this product and certified for the country of use.
- Use with power supply model ATS 065T-P/A240, manufactured by Adapter Technology Co Ltd. (RTW 1178-R).
- The power cord of the external power supply disconnects the product from the power source. Do not block the power cord or power supply; it must remain accessible to the user at any time.
- Connect and disconnect properly. Use only connectors specified for this product and fix them tight before use.
- Observe all terminal ratings and markings on the product. Consult the operating manual for further ratings information before making connections to this product.
- Do not apply a potential to any terminal that exceeds the maximum rating of that terminal.
- Avoid exposed circuitry. Do not touch exposed connections and components when power is present.
- Turn off and disconnect the power supply immediately if the unit produces unusual smells, noises or smoke, or if foreign substances (e. g. liquids) or foreign objects enter the unit.
- Because of the installed battery the unit shall not be exposed to excessive heat such as sunshine, fire, or similar.
- Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Do not cover the unit and do not place any objects or anything containing liquids on it.
- Do not insert your fingers or any other objects into the housing.
- Do not operate without cover plates or panels.
- Do not operate with suspected failures. If you suspect there is damage to the unit, have it inspected by qualified service personnel.
- Do not use this apparatus near water.
- Do not operate in wet/damp conditions.
- Do not operate in explosive atmosphere.
- Do not operate in dusty environments.

ATTENTION!

Always follow the safety precautions below to avoid the possibility of physical injury to you or others, or damage to the unit or other property. These precautions include, but are not limited to, the following:

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions to prevent the internal temperature from becoming too high.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Also keep away the unit from direct incident solar radiation.
- Keep product surfaces clean and dry. Clean only with dry cloth.
- Never use any solvent based liquids for cleaning the housing surfaces and the display.
- Do not place the unit in an unstable position where it might accidentally fall over.
- Before connecting any devices to the unit make sure that the power supply is disconnected.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Before moving the unit, remove all connected cables.
- When transporting or moving the unit, always take care not to scratch or damage the housing surfaces and the display.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Information on installed battery

The pcb features a battery socket with a 3 V Li/Mn coin cell battery, type CR 1225. It must be inserted from the side with its positive pole on top and its negative pole towards the pcb surface.

Environmental Considerations

Observe the following information about the environmental impact of the product and the following guidelines when recycling an instrument or component (product end-of-life handling):

- **Equipment Recycling**

Production of this equipment required the extraction and use of natural resources. The equipment may contain substances that could be harmful to the environment or human health if improperly handled at the product's end of life. In order to avoid release of such substances into the environment and to reduce the use of natural resources, we encourage you to recycle this product in an appropriate system that will ensure that most of the materials are reused or recycled appropriately.

- **Battery Recycling**

This product contains a lithium manganese dioxide (Li/Mn) battery, which must be recycled or disposed of properly according to your local government regulations.

- **Restriction of Hazardous Substances**

These instruments comply with and fall under category 9 Monitoring and control equipment of the regulations of the Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment of the European Parliament and Council from June 8th, 2011. This product may contain lead, cadmium and/or mercury in slight quantities. Please dispose of or recycle the electronic parts or devices according to your local government regulations.

Index of Content

Safety Instructions	3	
Important Safety Instructions	3	
Warning!	4	
Attention!	5	
Environmental Considerations	6	
Index of Content	7	
Before You Begin	8	
Introduction	8	
Scope of Delivery	10	
Installation	11	
Connection	12	
Pin Assignment	13	
Getting Started	15	
System Start-up	15	
Adapt the TouchMonitor to your Audio System	16	
Create Your Own Preset	18	
Working with Instruments and Presets	23	
		Delivered Presets
		25
		Software Modules (Licences Handling)
		42
		Software Update
		46
		Specifications (Extract)
		48
		EC Declaration of Conformity
		50
		RoHS Declaration of Conformity
		51
		CE and RoHS of Third Party Components
		52
		Licenses of the Implemented Software
		53

EN

Before You Begin



Introduction

Thank you for purchasing a model of the TouchMonitor TMR7 series. Loudness, true peak, PPM, audio vectorscope, moving-coil instruments, RTA, and correlation: The TMR7 TouchMonitor 4-channel solution featuring 7" touchscreen and the unique TouchMonitor operating concept integrates all metering options required in radio broadcasting to a solution made to measure.



Simple and flexible

The graphical user interface used in the TouchMonitor range is controlled simply by using your finger or a mouse. Instruments can be scaled, randomly positioned and combined in almost every way for optimized use of available screen space. Even multiple instruments of the same type, assigned to different input channels and configurations, can be displayed simultaneously. A context-sensitive, on-screen help feature and the intuitive operable menu system supports the user, allowing him to make setup changes with ease.

Audio I/O interface

TMR7's hardware and software are perfectly adjusted to radio-broadcast requirements and easily integrates into any studio environments. The four audio inputs provided by the two AES3 XLR ports are flexibly configurable for mono, stereo, or multichannel sources, providing separate instruments for each source. So TMR7 allows parallel monitoring of the on-air signal and a PFL source.

Licences

A totally modular software concept means that you only have to purchase features that you actually require. This puts you in control, defining the functionality of a TouchMonitor that suits your needs best. New instruments and functions can be added as software modules to the device at any time. Simply purchase and activate the corresponding licence.

Many display functions are available to choose from: the Real-Time Analyzer (RTA), loudness meters compliant to all relevant loudness standards, LRA and Chart, and the Premium PPM including Audio Vectorscope and Moving Coil instruments.



Scope of Delivery

Unpack the instrument, find your version below, and check, if you received all items listed. If components are missing, please contact your dealer. Recommended accessories, options and software licences are also listed.

TouchMonitor TMR7





Table-top unit TMR7

➤ with Audio Interface



2 x AES3 In
2 x AES3 Out


➤ Software Licence, if ordered




Loudness and
SPL display
SW20002




RTA - Real Time
Analyzer
SW20003



Premium PPM
+ Moving Coil
SW20006



Timecode
Reader
SW20008




Logging Data
Server (+Chart)
SW20014



Quick Start Guide


➤ Power supply



USB stick



Quick Start Guide



OEM version TMR7OEM

➤

➤

Installation

The TouchMonitor **TMR7** table-top unit is designed for free positioning on tables, desks, et. al. The OEM version **TMR7OEM** is designed for panel-mounting e. g. into mixing consoles. This version also can be mounted into common 19"/3U racks using optional mounting adapter **TM7-MA3U** or into standard 19" rack-mount cabinets for video racks using optional mounting adapter **TM7-MAVID**. With mounting adapter **TM7-MADT**, the OEM version can be remodelled to a table-top unit. All necessary power supply voltages are supplied through the +24 V DC - 1 A connector. Use with power supply model ATS 065T-P/A240, manufactured by Adapter Technology Co Ltd. (which is the external power supply unit RTW **1178-R** wide voltage power supply, included in TMR7 package, optional for TMR7OEM). The units feature a 7" VGA 16 : 9 touch screen. Optional an external standard 16 : 9 VGA monitor can be connected for external reading of the display. Optional an external computer mouse or a Wacom® graphics tablet can be connected to one of the USB interfaces. The other ports and interfaces are connected with the appropriate standard connection cables.



ATTENTION – Please read before installing:

- Before installing the unit please study the safety instructions and the information on connection and pin assignment.
- An external overcurrent protective device (2 A max.) shall be installed when using an external 24 V DC power supply!
- Make sure that the delivered power supply unit is not connected.
- Place the unit at a suited place or mount it acc. to the system requirements for OEM.
- Connect your signal sources and all your other components to the appropriate connectors, using the correct standard connection cables for the components. Take care about the pin assignment!
- Optionally, connect an external standard 16 : 9 VGA monitor to the VGA output, using a standard VGA connection cable. The VGA cable shall be of 15 m maximum length.
- Finally, connect the locking 4-pin low voltage connector of the external power supply to the +24 V DC - 1 A connector on the rear. Connect the external power supply to mains.
- The TouchMonitor will initiate its system startup sequence. After the boot-up the unit is ready for use.

Connection

TouchMonitor TMR7

External:


Standard VGA
Monitor 16 : 9



4-pin locking low voltage connector



24 V DC - 1 A




Pin Assignment

AES3 In 1, AES3 In 2 (transformer-bal., 3-pin XLR-F)

Pin: Function:

- 1 Shield/chassis
- 2 +, hot
- 3 -, cold




⚠ NOTE - The AES3 inputs are permanently terminated with $110\ \Omega$.

AES3 Out 1, AES3 Out 2 (transformer-bal., 3-pin XLR-M)

Pin: Function:

- 1 Shield/chassis
- 2 +, hot
- 3 -, cold



24 V - 1 A (4-pin locking low voltage connector, Typ Binder 710)

Pin: Function:

- 1 - 2 +24 V DC/+12 V DC
- 3 - 4 0 V



EN

⚠ NOTE - An external overcurrent protective device (2 A max.) shall be installed when using an external DC power supply!


USB-A

2 Full Speed USB 2.0 connectors for USB sticks (Licence handling, presets, updates) and external mouse or Wacom® tablet.

Pin Assignment (continued)

VGA (15-pin Sub-D-F)

Pin:	Function:
1	R Video signal
2	G
3	B
4 - 8	GND
9	+5 V
10 - 11	GND
12	SDA
13	H-sync
14	V-sync
15	SCI



GP IO (RJ-12 6P6C socket)


External control of functions defined in the Global Keyboard menu. The inputs defined as „active low“ have to be switched against 0 V (Pin 1).

Pin:	Function:
1	GND (0 V)
2 - 6	Function acc. to definition in the menu



Block diagram of the GPIO interface

(External view of the connector)



NOTE - The VGA cable shall not exceed 15 m lenght!

LAN

RJ-45 standard network connector (10/100 MBit)

Getting Started

System Start-up

Before connecting the TouchMonitor to the power supply, please make sure, that the following connections are made according to your unit (TM7, TMR7, TMR7 Smart, TM9) and to your individual needs:

- Analog and/or digital audio input signals (depending on the hardware configuration of your unit)
- Digital outputs (if available)
- Optional external standard 16 : 9 VGA monitor (not TMR7 Smart)
- Optional USB mouse
- LAN/Ethernet (if needed)
- Power supply

When the TouchMonitor is connected to the power supply, it will initiate its system startup sequence. After the boot-up the unit is ready for use.

We assume that you are starting your TouchMonitor for the first time. You now should make some global settings to adopt the unit to your audio system. After this short procedure you can create your first preset to work with.

EN



NOTE - The figures in the following paragraphs may show some options that are not available on your unit. The scope of available options depends on model (TM7, TMR7, TMR7 Smart, TM9), hardware configuration, and activated licences resp. installed software.


Adapt the TouchMonitor to your Audio System

The description below leads you through the main steps of the global settings to configure the TouchMonitor once for the use with your audio system. These settings are not altered by loading new presets.


1. If not visible, touch the empty space of the screen to display the control bar.



4. If needed, touch **Language** and select your language in the right half of the menu. The selection will be shown on the **Language** key.
The new language will be available after reboot.



2. Touch the **Menu** key in the right section of the control bar to access the menu system showing the **Main Menu**.



3. Touch the **System** key. This will access the **System Menu**. The **General** sub menu will be active (marked in the control bar).

3. Touch the **System** key. This will access the **System Menu**. The **General** sub menu will be active (marked in the control bar).

6. If your TM unit should use a defined reference source, touch the **Sync Reference** key and select from the items in the right half of the menu.

Info Number and type of available sync reference sources depends on model and scope of the installed audio interfaces.



7. Touch the **Clock** key, if you want to set the current date and time. Start the internal clock with touching the **Set time** key.





8. Touch the **Save** key to store your global settings. The unit turns back to normal display mode.

Create Your Own Preset


Presets are used to define and edit all the specific settings for your work flow. So you can create audio groups containing a defined signal source selection and one or more instruments sharing this domain and showing parameters of audio signals. Also you can create non-audio groups containing instruments, that are not related to audio input signals, like clock, hardware status monitor, or global keyboard.

If you want to create a preset from scratch, please proceed as follows:

1. If not visible, touch the empty space of the screen to display the control bar.
2. Touch the **Menu** key in the right section of the control bar to access the menu system starting with the **Main Menu**.
3. Touch the **Preset Management** key. The **Internal Presets** menu appears.
4. Touch the **New** button to create a new preset. A preset with an editable default name is created (see next figure, touch Preset Name to edit).




5. Touch the **New Audio** key to create the first audio group.





7. The **Mode** key appears and is marked, select your channel mode in the right half of the menu.

i The number of modes depends on your model and the activated software licences.




8. If the **Loudness and SPL display** software licence (SW20002) is activated resp. the unit is a TMR7 Smart, the **Select Loudness** sub menu appears. Select the loudness type you prefer.




9. The **Instruments** field appears on the left, and a list of the available instruments is shown on the right.

! The number of instruments depends on the activated software licences.



10. Touch the keys of the instruments you want to use. The icon of every selection is placed on the **Instruments** field on the left.




11. If you have done all your selections, touch the **Done** key. This returns you to the **Preset** menu.




! The Preset menu now shows the audio group you just created, marked with a small colored triangle in the upper left edge. In normal operation, all instruments of this group will always be identified by this color. The identifier colors make it easy to distinguish the group an instrument belongs to, if you have created several groups.

12. Touch the **View** key to start arranging the instruments on the screen. The defined groups containing the instruments are shown on the left (see next figure).




EN **i** The View Screen is a comprehensive editor used to position and size the instruments defined in the current preset. All instruments needed must be positioned before you can watch them in normal display mode.

13. Touch an instrument icon. It will be applied to the upper left edge of the graphical screen representation.




14. Use the **Position** and **Size** keys to resize the instrument and place it to another position.




15. Do so with the other instrument icons.


i In case of two or more instruments overlapping, a warning will be displayed. Move the overlapping instrument icon to an unused area. Use the **Position** and **Size** keys.



16. When the screen layout satisfies your demands (you also can rotate instruments), touch the **Save** key below in the control bar.



17. This will return you to normal display mode showing the new screen layout resp. the new preset you created.



Working with Instruments and Presets

In normal display mode the TouchMonitor shows the instruments and the screen layout defined in the currently loaded preset. You can use the control bar keys to operate a selected instrument or to load a new preset.


i If the control bar is not visible, just touch the screen. Then it will be displayed for some seconds to make your selection.

If you want to use the functions of an instrument, please proceed as follows:


1. Touch the screen area of the instrument you want to use. It will be put into focus. The left section of the control bar now shows the specific functions of the focused instrument.
i The current selected instrument is marked with a colored frame around. It represents the identifier color like the colored triangle.

2. Select the desired function.


i If there are more than 6 functions, use the **More** key.
If a function key opens another level of functions, then use the **Close** key to get back to the previous level.



If you want to load another preset, please proceed as follows:




1. Touch the **Load Preset** key in the right section of the control bar.
A menu page with a list of presets available is shown.



2. Touch the preset you want to use.

Info The current selected and used preset is marked with green color as active. In normal display mode, the name of the active preset is displayed in the lower right edge of the screen.

3. The selected preset is loaded. The unit automatically switches back to normal display mode and displays the selected preset.



Info Depending on the unit's type (except TMR7 Smart) the functions like Loudness or Vectorscope shown on the screenshots require further software licences being activated.

Delivered Presets

The USB flash drive delivered with TouchMonitor TMR7 contains 16 predefined presets presenting a cross-section of the applications and standards supported by the unit. Using these presets, you can start working with the TMR7 right out of the box, but you also can adapt them to your individual needs. For the OEM version all presets are also available for vertical use. Find screenshots and the description of the most important features on the following pages.

Load presets from USB flash drive

1. Touch the screen, then **Load Preset** in the right part of the control bar (lower edge of the screen).
2. Touch **External**. The available presets are displayed.
3. Touch the preset you prefer. It will be loaded and will be available for normal operation after some seconds.



NOTE - Please note that the TouchMonitor will only allow to import presets, if the hardware and licences of the unit matches with the instruments and hardware setup of the preset. In case of a mismatch an error message will be seen and the import will be refused.

 Short descriptions of the instruments used in the presets as well as some hints for a fast interpretation of the readings are presented on the internal help page of the focussed instrument (touch **Help** in right edge of the control bar) or clicking the **Function Description/Instruments** options of the manual stored on the USB flash drive.

EN

DEFAULT




Input: AES3 1

Program Meter Scale: Dig60: 0..-60 dB (-60 to 0 dBFS)

Instruments: Program Meter (PPM mode), Correlator

⚠ NOTE - This preset is fixed to secure basic display functionality. It can't be edited. Touching keys referred to presets shows no reaction.

ATSC+PPM (only available with activated licence SW20002)



Group: Stereo 1

Input: AES3 1

Loudness: ATSC A/85

Program Meter Scale: Dig60: 0..-60 dB (-60 to 0 dBFS)

Instruments: Program Meter (PPM mode), Correlator, Vectorscope, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

Keys: Loudness Num Keys: Start, Stop, Reset Loudness

EN

DUAL ATSC (only available with activated licence SW20002 and SW20006)



Group: Stereo 1

Input: AES3 1

Loudness: ATSC A/85

Program Meter Scale: Dig60: 0..-60 dB (-60 to 0 dBFS)

Instruments: Program Meter (PPM mode), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Group: Stereo 2

Input: AES3 2

Loudness: ATSC A/85

Program Meter Scale: Dig60: 0..-60 dB (-60 to 0 dBFS)

Instruments: Program Meter (PPM mode), Vectorscope,
Loudness Sum (M, S), Loudness Num (I)

Global Keyboard: Keys: Start, Stop, Reset

DUAL EBU (only available with activated licence SW20002 uand SW20006)



Group: Stereo 1

Input: AES3 1

Loudness: EBU R128

Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)

Instruments: Program Meter (PPM mode), Vectorscope, Loudness Sum (M, S), Loudness Num (I)

Group: Stereo 2

AES3 2

EBU R128

Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)

Instruments: Program Meter (PPM mode), Vectorscope, Loudness Sum (M, S), Loudness Num (I)

Global Keyboard: Keys: Start, Stop, Reset

DUAL+RTA EBU (only available with activated licences SW20002 and SW20003)



Group: Stereo 1
 Input: AES3 1
 Loudness: EBU R128

Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)
 Instruments: Program Meter (PPM, Headroom -13 dB, scale mark -18 dBTP), RTA (1/3-Oktav, linear, fast), Correlator, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)
 Keys: Loudness Num Keys: Start, Stop, Reset Loudness

Group: Stereo 2
 Input: AES3 2
 Loudness: EBU R128
 Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)
 Instruments: Program Meter (PPM, Headroom -13 dB, scale mark -18 dBTP), RTA (1/3-Oktav, linear, fast), Correlator, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)
 Keys: Loudness Num Keys: Start, Stop, Reset Loudness

MC BBC EBU (only available with activated licences SW20002 and SW20006)




Group: Stereo 1
Input: AES3 1
Loudness: EBU R128
Program Meter Scale: BR IIa: 7..1
Instruments: Moving Coil Meter (PPM mode Dual+M/S vertical), Vectorscope, Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

Group: Stereo 1
Input: AES3 1
Loudness: EBU R128
Program Meter Scale: Loudness
Instruments: Moving Coil Meter (Loudness mode Dual)

EN

MC VU ATSC (only available with activated licences SW20002, SW20003 and SW20006)



Group: Stereo 1
Input: AES3 1
Loudness: ATSC A/85
Program Meter Scale: VU digital
Instruments: Moving Coil Meter (VU mode Stereo Horizontal), Vectorscope, RTA (1/3-Oktav, linear, fast), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

PPM+VSC ARD



EN

Group: Stereo 1

Input: AES3 1

Program Meter Scale: ARD9: +9..-60 dB (-60 to +9 dB)

Instruments: Program Meter (PPM mode), Correlator, Vectorscope

Global Keyboard:

Keys in Preset mode: PPM BBC, PPM NOR-
DIC, TRUE PEAK (allows quick changes to
presets 9, 10 and 16. These are configured
in the same way, they only use different PPM
scales)

PPM+VSC BBC



Group: Stereo 1
Input: AES3 1
Program Meter Scale: BR IIa: 7..1
Instruments: Program Meter (PPM mode), Correlator, Vectorscope

Global Keyboard:

Keys in Preset mode: PPM ARD, PPM NOR-
DIC, TRUE PEAK (allows quick changes to
presets 8, 10 and 16. These are configured
in the same way, they only use different PPM
scales)

PPM+VSC NORDIC



Group: Stereo 1

Input: AES3 1


Program Meter Scale: Nordic: +12..-42 dB

Instruments: Program Meter (PPM mode), Correlator,
Vectorscope

Global Keyboard:

Keys in Preset mode: PPM ARD, PPM BBC,
TRUE PEAK (allows quick changes to presets
8, 9 and 16. These are configured in the same
way, they only use different PPM scales)

R128+PPM (only available with activated licence SW20002)



Group: Stereo 1

Input: AES3 1


Loudness: EBU R128

Program Meter Scale: Dig60: 0..-60 dB (-60 to 0 dBFS)

Instruments: Program Meter (PPM mode), Correlator, Vectorscope, Loudness Sum (M, S, I), Loudness Num (M, S, I, LRA, TPmax, Mmax, Smax)

Keys: Loudness Num Keys: Start, Stop, Reset Loudness


ST ATSC (only available with activated licence SW20002)



Group: Stereo 1
Input: AES3 1
Loudness: ATSC A/85
Instruments: Vectorscope, LRA (MagicLRA + I mode),
Loudness Num (M, S, I, LRA, TPmax, Mmax,
Smax)
Keys: Loudness Num Keys: Start, Stop, Reset Loud-
ness


EN

ST EBU (only available with activated licence SW20002)



Group: Stereo 1
Input: AES3 1
Loudness: EBU R128
Instruments: Vectorscope, LRA (MagicLRA + I mode),
Loudness Num (M, S, I, LRA, TPmax, Mmax,
Smax)
Keys: Loudness Num Keys: Start, Stop, Reset Loud-
ness

ST+PFL ATSC (only available with activated licences SW20002 and SW20006)




Group: Stereo 1
Input: AES3 1
Loudness: ATSC A/85
Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)
Instruments: Program Meter (PPM Classic mode), Vector-scope, Loudness Sum (M, S), Loudness Num (I, TPmax)

Group: Stereo 2
Input: AES3 2
Loudness: ATSC A/85
Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)
Instruments: Program Meter (PPM Classic mode), Loudness Num (I, TPmax)

Global Keyboard: Keys: Start, Stop, Reset

ST+PFL EBU (only available with activated licences SW20002 and SW20006)



Group: Stereo 1

Input: AES3 1

Loudness: ATSC A/85

Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)

Instruments: Program Meter (PPM Classic mode), Vector-scope, Loudness Sum (M, S), Loudness Num (I, TPmax)

Group: Stereo 2

Input: AES3 2

Loudness: ATSC A/85

Program Meter Scale: TP60: +3..-60 dB (-60 to +3 dBTP)

Instruments: Program Meter (PPM Classic mode, scale mark -18 dBTP), Loudness Num (I, TPmax)

Global Keyboard: Keys: Start, Stop, Reset

TRUE PEAK



Group: Stereo 1

Input: AES3 1

Program Meter Scale: TP60: +3,-60 dB (-60 to +3 dBTP)

Instruments: Program Meter (PPM mode), Correlator, Vectorscope

Global Keyboard:

Keys in Preset mode: PPM ARD, PPM BBC, PPM NORDIC (allows quick changes to presets 8, 9 and 10. These are configured in the same way, they only use different PPM scales)

Software Modules (Licences Handling)

The TouchMonitor features a modular software concept that enables you to add new functions and instruments to your unit at any time. The **Licences** menu is used to view the licences currently installed on the TouchMonitor and to acquire new licences. Instruments and functions already activated are marked with an **Installed** sign. Instruments and functions that are not installed have an **order** key. On the **Licences** menu you only will find licencing options that are provided for your model and were already available at the release date of the software version installed on the unit.



NOTE - Some licences require others to be installed first before you can acquire them. Please note the corresponding information while purchasing licences.



NOTE - The figures in the following paragraphs may show licences that are not available on your unit depending on model (TM7, TMR7, TM9), and hardware configuration.

If you want to acquire new licences, please proceed as follows:


1. Insert a USB flash drive to one of the USB ports on the rear panel.
2. Touch the empty space of the screen or one of the displayed instruments, the control bar appears.



3. Touch the **Menu** key in the right section of the control bar to access the menu system showing the **Main Menu**.



4. Touch the **Licences** key. The available software licences are displayed, the activated ones marked with **Installed**.




5. Touch the **order** keys of the licences you want to acquire.



6. Touch the **Export Requests** key displayed in the left section of the control bar.

Info The TouchMonitor will establish a folder structure on the USB flash drive named **/rtw/licence**. An encrypted licence request file (nnn_nn.lrf) depending on the individual serial number of the hardware unit is stored to this folder.

7. Wait until the menu page confirming the successful export of the licence request file is displayed.



8. Touch the **Done** key. This turns you back to the **Main Menu**.

Info With the USB flash drive inserted, there are additional keys on the right to export or import individual presets or the global settings to the resp. from the USB flash drive.



9. **Wait some seconds in order not to damage the licence request file!**

Not until then remove the USB flash drive from the TouchMonitor, insert it to a USB port of your computer and upload the licence request file to our web shop: <https://www.rtw.com/en/shop.html>. You can also send the file to your sales representative.

Info Alternatively to the information of step 6, in single cases this file may also be found in folder **/rtw/tm7h/licence** resp. **/rtw/tm9h/licence**.

10. After purchasing the licence, a new file (nnn_nn.lrf) containing the licence request file will be sent to you.

Info The returned licence file is only valid for the individual unit on which the licence request file was created.

11. The licence file (nnn_nn.lrf) shall be stored to the same folder as the licence request file on the USB flash drive.


12. **Unmount** the USB flash drive from the computer system! Not till then remove it from your computer!

ATTENTION! - Unmounting from the computer system shall be performed to avoid damage of the copied update file!

13. Remove the unmounted USB flash drive from your computer and insert it to one of the USB ports on TouchMonitor's rear panel.


14. Access the **Licences** menu as described in steps 2. to 4.

15. The licence file will be recognized, and an **Import Licences** key will be shown in the left section of the control bar.



16. Touch the **Import Licences** key to import the licence file to the unit.

17. When the import is finished, reboot the TouchMonitor by touching the **Back** key.



18. The licenced instrument or function is now permanently available.

19. If you have converted a TM7 or TM9 from TC electronic® to an RTW unit with licence SW20021, please repeat a software update (can be done with the same firmware as running on the device). Then, the unit will start up with the RTW boot screen.

Software Update

If you want to add new functions and instruments to your unit at any time, periodic maintenance of the system software (firmware) is necessary, because you only will find options and licences that were provided for your model and were already available at the release date of the software version installed on the unit.

Software updates are available from your sales partner or the download area of our web site (<https://www.rtw.com/en/support/manuals-software.html>). There, click „Audio Monitors“, then choose the option corresponding to your model.



If you want to update your software, please proceed as follows:

1. Copy the update file (rtw-tm-fw-n-n.bin, n-n: firmware version) into the main directory of a USB flash drive.
2. **Unmount** the USB flash drive from the computer system! Not till then remove it from your computer!

ATTENTION! - Unmounting from the computer system shall be performed to avoid damage of the copied update file!

3. Remove the unmounted USB flash drive from your computer and insert it to one of the USB ports on TouchMonitor's rear panel.



4. If not visible, touch the empty space of the screen to display the control bar.
5. Touch the **Menu** key in the right section of the control bar, then the **System** key in the **Main Menu**.
6. Touch the **Special** key. The additional **Start Firmware Update: rtw-tm-fw-n-n** key is displayed.
7. Touch the key. The update starts and takes about 10 minutes.



8. When the update is finished, the TouchMonitor reboots automatically.
9. Touch the **Menu** key in the right section of the control bar, then the **Info** key in the **Main Menu**.
10. Check the **Software Version** (the designation of the update file should be displayed), the **Serial Number** and the **Model Number**.

Specifications (Extract)

System

General

Power requirements:	+24 V DC (2 A overcurrent protective device shall be installed!)
Current drain:	1 A nominal current, 2.5 A power-up current (10 μ sec.)
Power dissipation:	approx. 8.5 W
Display:	7" TFT touch screen 16 : 9 (800 x 480 pixel)
Connectors:	1 x 15-pin Sub-D-F; VGA output with 800 x 480, 65,536 colors, 60 Hz, for connection of an external 16 : 9 VGA monitor, internal selectable 4 : 3 mode 1 x 4-pin locking low voltage typ 710 (DC) 2 x USB A; USB 2.0 Full Speed connectors for: <ul style="list-style-type: none">USB sticks for licence handling, preset export and import, software updatesexternal computer mouse or Wacom® graphics tablet 1 x GPIO (RJ-12-6P6C, for remote control of defined functions) 1 x LAN (RJ-45) 2 x XLR-F (2 x AES3 In) 2 x XLR-M (2 x AES3 Out)
Dimensions (W x H x D):	<ul style="list-style-type: none">TMR7: 198 x 139.5 (163) x 46 (95) mm (with table-stand)TMR7OEM: 188 x 109 x 45 mm
Weight:	approx. 2.7 kg (without power supply)
Operating temperature:	in the range from +5° to +40° C

Functions (with all licences activated)

- Operating using a finger (touch screen), mouse, or tablet
- Instruments can be freely scaled and randomly positioned
- Multiformat 4-ch. PPM (2-ch. Stereo, 2 x 2-ch. Stereo, single ch., multichannel up to 4 ch.)
- Loudness-Meter: EBU R128, ITU-R BS.1770-4/1771-1, ATSC A/85, ARIB, OP-59, AGCOM, CALM Act, LEQ(M), TASA, SAWA, custom, SPL meter
- Loudness Test Time Control
- Loudness Range instrument (LRA)
- Logging Data Server with Logging and Chart instruments
- Moving Coil instrument (BR, VU, Loudness, BBC mode)
- Gain reduction instrument
- Stereo Correlator
- 31, 61, and 122 band spectrum analyzer
- 2-channel Audio Vectorscope (4 instances available)
- AES3 status monitor
- Numerical displays, Timecode

Digital Inputs

Inputs:	2 AES3 inputs (transformer balanced, 110 Ω), 2 XLR-F connectors, 3-pin
Sampling rates:	44.1, 48, 96 kHz; synchronisation to digital input signal or internal clock

Digital Outputs

Outputs:	2 AES3 outputs, XLR-M connector, 3-pin
Sampling rates:	referenced to digital inputs or internal clock

Basic PPM (Standard Software)

General

Input sources:	digital via XLR audio interface (AES3)
4-ch. peakmeter:	2-ch. Stereo, 2 x 2-ch. Stereo, single channel, multichannel for up to 4 channels
Displays:	<ul style="list-style-type: none">Peak levelPeak holdNumerical value of the display
Functions:	<ul style="list-style-type: none">Gain (+20 dB, +40 dB depending on selected standard)Peak hold on/off, Memory, Reset

Digital Peakmeter

Word width:	24 bit
Digital scales:	<ul style="list-style-type: none">TP60: +3 .. -60 dBDig60: 0 .. -60 dBDIN5: +5 .. -50 dB,Nordic: +12 .. -42 dB,BR IIa: 7 .. 1 (British),BR IIb: +12 .. -12 dB (British),
Headroom/Headr. Ref:	adjustable in 1 dB steps in the range from 0 to -20 dB
Operation range:	adjustable in 1 dB steps in the range from 0 to -20 dB
Integration time (Attack):	acc. to corresponding standard or selectable: Sample, 20 ms, 10 ms, 1 ms, 0.1 ms, additional 150 ms for British scales
Gain:	+20 dB, +40 dB depending on selected standard
High-pass filter:	Off, 5 Hz, 10 Hz, 20 Hz
Peak hold display:	1 s, 2 s, 4 s, 10 s, 20 s, 30 s, manual reset or off
Over display hold time:	1 s or manual
PPM Over threshold:	Full Scale, Full Scale -1LSB, Full Scale -2LSB, -0.1 dBFS, -0.5 dBFS, -1 dBFS, -2 dBFS, -3 dBFS
PPM Over attack time:	1 to 15 samples
PPM Over word width:	16 to 24 Bit, selectable
True Peak Over threshold:	-1.0 dBTP, -2.0 dBTP, -3.0 dBTP, -4.0 dBTP

Audio Vectorscope

Display mode:	2 channel
Inputs:	L/R (Stereo signal with the input channels of the selected audio group)
AGC:	fast/slow
Grid:	L/R or M/S

AES3 Status Monitor

Displays:	<ul style="list-style-type: none">Channel data are displayed as plain text, hex or binaryChannel selectableAudio bit activityHardware status
-----------	---

Global Keyboard

The Global Keyboard is used for simultaneous control of defined functions in multiple instruments, and for preset recall. It also allows the external control with the integrated GP IO interface.

Gain Reduction

Display:	1 bargraph for Mono and Stereo formats, up to 4 bargraphs in multichannel mode
Input:	Data stream via TCP/IP and LAN (ethernet) interface
Input routing:	external featured streams selectable
Marker:	adjustable threshold for the definition of upper and lower display section
Colors:	32 colors for each bargraph section

Please read the TouchMonitor TMR7 data sheet for the complete specifications. The data sheet is available on the TMR7 product page of RTW's web site or as part of the manual stored on the delivered USB flash drive..

EN

EC Declaration of Conformity

EC Declaration of Conformity | Directive 2004/108/EG and Directive 2006/95/EG

We, RTW GmbH & Co. KG, Am Wassermann 25, 50829 Köln, Germany, declare under sole responsibility that the products of the

RTW TouchMonitor TMR7 Series

(OEM unit/table-top unit)

meet the intent of the Directive 2004/108/EG and the Directive 2006/95/EG. Compliance was demonstrated to the following specifications as listed in the official Journal of the European Communities:

EMC 2004/108/EG

EN 61000-6-3: 2012-11 Emissions:

EN 55022: 2011-12 Class B, radiated

EN 55022: 2011-12 Class B, conducted

EN 61000-6-1: 2007-12-01 Immunity:

EN 61000-4-2 + A1 + A2: 2002-02-01

EN 61000-4-4: 2005-09-01

EN 61000-4-5: 2007-08-01

Safety 2006/95/EG

EN 60950-1: 2007-01-01

Tested and documented by the following companies:

RTW GmbH & Co.KG, Cologne

Date and signature of the responsible person:

2013-03-14

on behalf of RTW



RoHS Declaration of Conformity

RoHS Declaration of Conformity for TMR7 | Directive 2011/65/EU

We, RTW GmbH & Co. KG, Am Wassermann 25, 50829 Köln, Germany, declare under sole responsibility that the products of the

meet the intend of the Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment of the European Parliament and Council from June 8th, 2011.

RTW TouchMonitor TMR7 Series

consisting of the components:

- TMR7 (TMR7 main unit with digital audio interface in a table-top frame)
- TMR7OEM (TMR7 main unit with digital audio interface, OEM)
- TM7-MA3U (Mounting adapter: OEM in 19"/3U/42HP)
- TM7-MAVID (Mounting adapter: OEM in 19" video racks)
- TM7-MADT (Mounting adapter: OEM in table-top frame)


Tested and documented by the following companies:

RTW GmbH & Co.KG, Cologne

Date and signature of the responsible person:

2017-04-24

on behalf of RTW



CE and RoHS of Third Party Components



Further components of the TouchMonitor TMR7 units are delivered from third party companies, which declare the EC and RoHS conformity of these products:

- 1178-R (power supply 100 - 240 V AC/24 V DC, 2,71 A)
Supplier: Dehner-Elektronik
Manufacturer: Adapter Technology Co., Ltd.
CE Certificate No. T150115D02-E
RoHS conformity is declared together with EC declaration.
UL reference TH/SPC-1411065-SPC
- Attached USB flash drive
Supplier: Blue Chili
Manufacturer:
EC conformity No. E0700256
RoHS conformity Nr. R0808179

This external power supply is UL Listed for CAN/US, model
ATS 065T-P/A240, manufactured by Adapter Technology Co Ltd.
(RTW 1178-R), Class II double insulated, rated:
Input: 100 - 240 V, 47 - 63 Hz, 1 A max.
Output: 24 Vd.c., 2.71 A, 65 W.



Licenses of the Implemented Software

In addition to the hardware the RTW TouchMonitor 7" and 9" Series products also include a software package for which a variety of licenses apply. Detailed information and the licenses can be found in the **Info** menu of your device (**Menu -> Info -> License Informationen**) or in the detailed operating manual, which is stored to the attached USB flash drive. Below a short overview:

1. Software produced by RTW GmbH & Co. KG.

This software may only be used for the proper operation of the product as described in the documentation (application, DSP programs, boot loader). This software is the property of RTW GmbH & Co. KG and is protected by German and international copyrights.

2. Open source software, released under the GPL and LGPL of the Free Software Foundation (FSF).

3. Software, released under the LGPL of the Free Software Foundation (FSF), but with specific exceptions

4. Software, released under the MIT license.

5. Special licenses

6. Further license information

7. Source Code Offer / GPL

The software included in the product contains copyrighted software that is licensed under the GPL. A copy of that license is included in this document below. You may obtain the complete Corresponding Source code from us for a period of three years after our last shipment of this product by sending us an email to support@rtw.com. This offer is valid to anyone in receipt of this information.

8. No Warranty GPL

Cologne, November 20th, 2019

Depending on the model the start screen of the TouchMonitor contains an adapted image based on the photography "Cologne_CathedralNight-6.jpg" of Lukasz Kryger, Edinburgh, Scotland. The images fall under the Creative Commons Attribution 2.0 Generic License (http://commons.wikimedia.org/wiki/File:Cologne_CathedralNight-6.jpg, <http://creativecommons.org/licenses/by/2.0/deed.en>).



RTW GmbH & Co. KG

Am Wassermann 25 | 50829 Köln | Germany

Phone: +49 221.70 913-0 | Fax: +49 221.70 913-32

Internet: www.rtw.com | E-Mail: rtw@rtw.com

